



*The Flying Culinary Circus.*

**FCCBBQ**





**Digital Thermometer**  
USER MANUAL

# The Device



Probe sockets




Probe with cable



AAA battery x 2  
(not included)

# Instructions

Two AAA size batteries are needed for this device. Make sure they are put in the right direction by following the icons on the unit.



1. Open the battery cover.
2. Put in batteries, noticing the icons that show directions.



3. Lock the battery cover.

## Download the APP

Search the keyword FCC BBQ in Appstore or Google Play, or scan the following QR code with your phone.

Download and install it for free.

Make sure your phone meet the requirements:

- iPhone 4S, and later models;
- iPod touch 5th, ipad 3rd generations and later models,
- all ipad mini;
- Android devices running version 4.4 or later, with blue-tooth 4.0 module.




[WWW.FCCPRODUCTS.NO](http://WWW.FCCPRODUCTS.NO)

## Install the probes

The device will keep scanning the sockets when its power is switched on, the Probe Indicators will blink one by one from 1 to 2 where probes are plugged in.

Then insert the probes into the food, make sure the front tip of the probe is in the center of the food to get accurate temperature.



## Pair with your phone

1. Press and hold the power button on the device for 3 seconds to power it on.
2. Keep the bluetooth connection on the phone activated.
3. Launch the app, and follow the instructions in the app to pair and activate the device.
4. Connected successfully.

Bluetooth Indicator

No icon

Icon blinking


Icon fixed

Once paired the device with your phone, you don't need to do it again, unless you change to other phones.

## Enjoy your barbecue time

Choose the food type and preference for the food where each probe is inserted, the app and the device will display its current and target temperature.

When the food is ready, the app and the device will alarm.



The user interface of the app may be changed when upgraded. Please follow the instructions in the app.

## Power ON/OFF

Power ON:

Press and hold the power button for 3 seconds.

Power OFF:

Press and hold the power button for 3 seconds.

Auto-off after 8 hours out of connection with phone.

# WARNING

- The heat resistance varies in different components of the probe.
- DO NOT put the probes directly in the fire frame.
- The probes are NOT dishwasher safe.

**Teflon cable  
with stainless steel mesh**

(Length: about 115cm

250°C

For long-time monitoring



**Sensor**

250°C / 482°F

For long-time monitoring

300°C / 572°F

For instantaneous test

## Consumer contact

This product is covered by a warranty in accordance with consumer legislation. It has undergone strict quality controls and testing at the factory.

If there are any parts missing or the product has been damaged, please contact your dealer or the consumer contact below for help.


Faults due to misuse, lack of maintenance or modification of the product will invalidate the warranty.

Damaged parts not due to a fault with the product will be invoiced according to our price list with and added carriage and administration fee.

If new parts are needed or in the event of a warranty claim, please contact your dealer or consumer contact:

### FCC PRODUCTS AS

KJELLER VEST 3, 2007 KJELLER, NORWAY

 +47 924 78 600

 [support@fccproducts.no](mailto:support@fccproducts.no)

[www.fccproducts.no](http://www.fccproducts.no)

Always attach your receipt when making a warranty claim.

Produced in China for FCC Products AS

We are always looking for ways we can improve our products. Therefore, we reserve the right to change technical specifications at any time. You will always find the latest manual on [www.fccproducts.no](http://www.fccproducts.no).